


1

2

3

4

App Download



Account Register

←

Register

Enter E-mail or Phone Number

International

E-mail

Verification Code Send

☐ I have read and agreed to T&Cs Privacy Policy

Next

Switch to phone registration

← Choose Region

① Please select the region corresponding to your business scope. The system will register you in the chosen region based on your selection.

Mainland China

International ✓

☐ Other Asian countries/regions

☐ Europe

☐ Oceania

☐ Africa

☐ North America

☐ South America

☐ Antarctica

Not sure how to choose?

Confirm

Account Register

←

Register

Enter Account Info

*Name

Username

*Password

A combination of letters and numbers with more than 8 characters and 10 characters

text

10%

Account Register

The image displays two sequential screenshots from a mobile application used for account registration.

Left Screenshot: Register

- Header: Register
- Sub-header: Enter Business Info
- Form Fields:
 - Business Type**: Set to Enterprise (highlighted with a red box and a red arrow pointing to the right screenshot).
 - *Business Name**: Enter Business Name
 - Business Area**: China
 - Type**: Installation O&M Provider
- Next Step: A blue button labeled "Next".

Right Screenshot: Select Business Type

- Header: Select Business Type
- Options:
 - Enterprise (Selected, indicated by a blue checkmark)
 - Individual

Account Register

The image displays two screenshots of the Midea HICONICS account registration process.

Left Screenshot: Register Screen

- Header: Register (Enter Business Info)
- Business Type: Enterprise >
- *Business Name: Enter Business Name >
- Business Area: China >** (This field is highlighted with a red box in the original image)
- Type: Installation O&M Provider >
- Next button

Right Screenshot: Select Business Area

- Header: Select Business Area
- China ✓
- Åland Island
- Afghanistan
- Albania
- Algeria
- American Samoa
- Andorra
- Angola
- Anguilla
- Antarctica
- Antigua and Barbuda
- Argentina
- Armenia
- Aruba

A red arrow points from the 'Business Area' field in the left screenshot to the 'China' option in the right screenshot.

Account Register

The image displays two screenshots of the Midea HICONICS account registration process.

Left Screenshot: Register

Header: Register
Sub-header: Enter Business Info

Fields:

- Business Type: Enterprise >
- *Business Name: Enter Business Name >
- Business Area: China >
- Type: Installation O&M Provider > (highlighted with a red box)

Next button (highlighted with a red box)



Right Screenshot: Select Type

Header: Select Type


Options:


- Installation O&M Provider (selected, indicated by a checkmark)
- Investors
- Distributor
- Manufacturer

App Login



Add Power Plant





Add Power Plant

Cancel Create a Plant Save

Cover



Change

Name

Required Field

Location

Longitude116°29'32.4"
Latitude39°45'21.9" >

Region

China/Beijing/Beijingchengqu/
Daxingqu >

Address

Required Field

Capacity(kWp)

Required Field

System Type ?

☐ PV + Grid

☐ PV + Grid + Consumption

☒ PV + Grid + Consumption + Battery

Plant Type ?

☒ Residential

☐ Commercial

☐ Industrial

Cancel Create a Plant Save

Plant Type ?

☒ Residential

☐ Commercial

☐ Industrial

☐ Ground Mounted

Azimuth(°) ?

Optional, 0~360°

Tilt Angle(°) ?

Optional, 0~90°

On-grid Date ?

2024-05-02 >

Time Zone

(UTC+08:00)
Beijing,Chongqing,Hong Ko... >

Currency

CNY >

Unit Price(CNY/kWh)

Optional

Total Cost(CNY)

>

Add a Logger

Create a Plant

Done

Your plant has been created. Please follow the steps below to complete system commissioning.



Add Datalogger

Scan code and add datalogger to realize plant data monitoring

If you need to add multiple dataloggers, please click the "Done" button in the upper right corner and add in the plant details




Authorize end users

Authorize the plant to the end user, and the user can also watch the monitoring

If you need to authorize businesses and internal members, please click the "Done" button in the upper right corner and add in the plant details



Add a Logger




Add a Logger




Add a Logger



Add a Logger



Add a Logger



Light	Implication	Instruction
	Communicate with base station	1.Light off: Connection to the router failed. 2.On 1s/Off 1s (Slow flash) : Connection to the router succeeded. 3.Light on: Connection to the server



Overseas Technical Support Dep.
13 May 2024



